

**TAURUS 200  
EFI**

**SERVICE MANUAL**

## NOTICE

This manual was produced by the NUBULA Group primarily for NUBULA dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on NUBULA vehicle should have a basic understanding of the mechanical ideas and the procedures of vehicle repair. Repairs attempted by anyone without this knowledge are likely to render the vehicle unsafe or unfit for use.

NUBULA Group is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized dealers and will appear in future editions of this manual where applicable.

### NOTE:

Designs and specifications are subject to change without notice.

---

## IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**



Failure to follow WARNING instructions **could result in severe injury or death** to the vehicle operator, passengers, bystanders, or persons checking or repairing the vehicle.

### CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the vehicle.

### NOTE:

A NOTE provides key information to make procedures easier or clearer.

# CONTENTS

<b>CHAPTER1 General Information.....</b>	<b>1.1</b>
<b>CHAPTER2 Maintenance.....</b>	<b>2.1</b>
<b>CHAPTER3 Engine.....</b>	<b>3.1</b>
<b>CHAPTER4 Chassis.....</b>	<b>4.1</b>
<b>CHAPTER5 Final Drive.....</b>	<b>5.1</b>
<b>CHAPTER6 Brakes.....</b>	<b>6.1</b>
<b>CHAPTER7 Electrical.....</b>	<b>7.1</b>



Never run an engine in an enclosed area. Carbon monoxide exhaust gas is poisonous and can cause severe injury or death. Always start engines outdoors.

Gasoline is extremely flammable and explosive under certain conditions. Battery electrolyte is poisonous. It contains sulfuric acid. Serious burns can result from contact with skin, eyes or clothing. Always keep alert and wear protection.

Exhaust system components are very hot during and after use of UTV. Never service when the engine is warm or hot. Escaping steam from cooling system or hot oil from the machine can cause severe burns. The engine must be cool before service.

Crate of the UTV and parts in the UTV maybe have sharp edge. Should always pay attention and wear protection.

# CHAPTER 1 GENERAL INFORMATION



The parts of different types/ variants/ versions maybe un-interchangeable, even some parts have almost same appearance. Always refer to Parts Manual of each UTV model for spare parts information and service.

## 1.1 IMPORTANT INFORMATION

- 1.1.1 PREPARATION FOR REMOVAL PROCEDURES
- 1.1.2 REPLACEMENT PARTS
- 1.1.3 GASKETS, OIL SEALS AND O-RINGS
- 1.1.4 LOCK WASHERS/PLATES AND COTTER PINS
- 1.1.5 BEARINGS AND OIL SEALS
- 1.1.6 CIRCLIPS
- 1.1.7 CHECKING OF CONNECTIONS
- 1.1.8 CONVERSION TABLE

## 1.2 V.I.N AND ENGINE SERIAL NUMBER

## 1.3 VEHICLE DIMENSIONS

## 1.1 IMPORTANT INFORMATION

### 1.1.1 PREPARATION FOR REMOVAL PROCEDURES

1. Remove all dirt, mud, dust and foreign material before disassembly.
2. Use proper tools and cleaning equipment.
3. When disassembling the machine, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been mated through normal wear. Mated part must always be reused or replaced as an assembly.
4. During machine disassembly, clean all parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

### 1.1.2 REPLACEMENT PARTS


Use only genuine parts for all replacements. Use recommended oil and grease for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

### 1.1.3 GASKETS, OIL SEALS AND O-RINGS

1. Replace all gaskets seals and O-rings when overhauling the engine. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.

### 1.1.4 LOCK WASHERS/PLATES AND COTTER PINS


Replace all lock washers/plates and cotter pins after removal. Bend lock tabs along the bolt or nut flats after the bolt or nut has been tightened to specification.



### 1.1.5 BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, should apply a light coating of lightweight lithium base grease to the seal lips. Install oil bearings liberally, if it is appropriate.


① oil seal



**CAUTION:**


Do not use compressed air to spin the bearings dry. This will damage the bearing surfaces.

- ① Bearing

**1.1.6 CIRCLIPS**


Check all circlips carefully before reassembly. Always replace piston pin clips after one use. Replace distorted circlips. When installing a circlip ①, make sure that the sharp-edged corner ② is positioned opposite the thrust ③ it receives. See sectional view.

- ④ Shaft

**1.1.7 CHECKING OF CONNECTIONS**

Deal with stains, rust, moisture, etc. on the connector.

1. Disconnect:
  - Connector
2. Dry each terminal with an air blower.
3. Connect and disconnect the connector two or three.
4. Pull the lead to check that it will not come off.
5. If the terminal comes off, bend up the pin ① and reinsert the terminal into the connector.
6. Connect:
  - Connector

**NOTE:**

The two connectors should be clicked together.

7. Check for continuity with a tester.

**NOTE:**

- If there is no continuity, clean the terminals.
- Be sure to perform the steps 1 to 7 listed above when checking the wire harness.
- Use the tester on the connector as shown.



Never run an engine in an enclosed area. Carbon monoxide exhaust gas is poisonous and can cause severe injury or death. Always start engines outdoors.

Gasoline is extremely flammable and explosive under certain conditions. Battery electrolyte is poisonous. It contains sulfuric acid. Serious burns can result from contact with skin, eyes or clothing. Always keep alert and wear protection.

Exhaust system components are very hot during and after use of UTV. Never service when the engine is warm or hot. Escaping steam from cooling system or hot oil from the machine can cause severe burns. The engine must be cool before service.

Crate of the UTV and parts in the UTV maybe have sharp edge, always pay attention and wear protection.

### 1.1.8 CONVERSION TABLE

How to use the conversion table.

Use this table to convert METRIC unit data to IMPERIAL unit data.


METRIC		MULIPLIER	=	IMP
**mm	x	0.3937	=	**in
**cm	x	0.03937	=	**in

### CONVERSION TABLE


METRIC TO IMP			
	Known	Multiplier	Result
Torque	m·kg	7.233	ft·lb
	m·kg	86.794	In·lb
	cm·kg	0.0723	ft·lb
	cm·kg	0.8679	In·lb
Weight	kg	2.205	lb
	g	0.03527	oz
Distance	km/h	0.6214	mph
	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3927	in
	mm	0.03927	in
Volume/Capacity	cc(cm <sup>3</sup> )	0.03527	oz(IMP liq.)
	cc(cm <sup>3</sup> )	0.06102	cu·in
	lit(liter)	0.8799	qt (IMP liq.)
	lit(liter)	0.2199	gal(IMP liq.)
Miscellaneous	kg/mm	55.997	lb/in
	kg/cm <sup>2</sup>	14.2234	psi(lb/in <sup>2</sup> )
	Centigrade	9/5(°C)+32	Fahrenheit(°F)

## 1.2 V.I.N AND ENGINE SERIAL NUMBER


The vehicle identification number ① is stamped into the left side of the rear frame tube.



The engine serial number ② is stamped into left side of engine crankcase.



### 1.3 VEHICLE DIMENSIONS



**Note:**

The on-road equipment (rear view mirror, turn lights, etc.) are not Standard Equipment for USA.



# CHAPTER 2 MAINTENANCE



The parts of different types/ variants/ versions maybe un-interchangeable, even some parts have almost same appearance. Always refer to Parts Manual of each UTV model for spare parts information and service.

## **2.1 PERIODIC MAINTENANCE**

- 2.1.1 MARK ON THE FOLLOWING CHART
- 2.1.2 PERIODIC MAINTENANCE SCHEDULE
- 2.1.3 LUBRICATION RECOMMENDATIONS

## **2.2 THROTTLE PEDAL INSPECTION**

- 2.2.1 THROTTLE FREEPLAY
- 2.2.2 THROTTLE FREEPLAY INSPECTION

## **2.3 CHOKE ADJUSTMETN**

## **2.4 FUEL SYSTEM**

- 2.4.1 FUEL LINES
- 2.4.2 VENT LINES AND ROLL OVER VALVE
- 2.4.3 FUEL FILTER

## **2.5 TOE ALIGNMENT**

## **2.6 BRAKING SYSTEM INSPECTION**

- 2.6.1 PAD INSPECTION
- 2.6.2 HOSE/FITTING INSPECTION
- 2.6.3 ADJUSTING THE BRAKE PEDAL
- 2.6.4 ADJUSTING THE PARKING BRAKE

## **2.7 SUSPENSION SPRING RPELOAD ADJUSTMENT**

- 2.7.1 SUSPENSION
- 2.7.2 REAR SUSPENSION

## **2.8 WHEELS**

- 2.8.1 WHEEL REMOVAL
- 2.8.2 WHEEL INSTALLATION
- 2.8.3 WHEEL NUT TORQUE SPECIFICATIONS

## **2.9 TIRE PRESSURE**

- 2.9.1 TIRE INSPECTION
- 2.9.2 TIRE TREAD DEPTH

## **2.10 FRAME , NUTS , BOLTS , FASTENERS**

## 2.1 PERIODIC MAINTENANCE GENERAL CAUTION

### 2.1.1 MARK ON THE FOLLOWING CHART

**DL**: Due to the nature of the adjustments marked with a **DL** on the following chart, it is recommended that service be performed by an authorized dealer.

**▲**: Service/Inspect more frequently when operating in adverse conditions.

### 2.1.2 PERIODIC MAINTENANCE SCHEDULE

Careful periodic maintenance will help keep your vehicle in the safest, most reliable condition. Inspection, adjustment and lubrication intervals of important components are explained in the following chart on the following pages. Maintenance intervals are based upon average riding conditions and an average vehicle speed of approximately 16km/h (10 miles per hour). Vehicles subjected to severe use, such as operation in wet or dusty areas, should be inspected and serviced more frequently.

Inspect, clean, lubricate, adjust or replace parts as necessary.

**NOTE:** Inspection may reveal the need for replacement parts. Always use genuine parts available from your dealer.

Service and adjustments are critical. If you are not familiar with safe service and adjustment procedures, have a qualified dealer perform these operations.

A=Adjust      I=Inspect  
 C=Clean      L=Lubricate  
 D=Drain      R=Replace  
 T=Tighten to Correct Torque






	Item	Hours	When	Remarks
	Service (Main) Brake System	/	Pre-ride	I
	Parking Brake	/	Pre-ride	I
	Tires	/	Pre-ride	I
	Wheels	/	Pre-ride	I
	Frame nuts, bolts fasteners	/	Pre-ride	I
▲	Air Filter-Pre-Cleaner	/	Daily	I C
▲	Air Box Sediment Tube	/	Daily	D
	Headlamp Inspection	/	Daily	C apply dielectric grease to connector when replaced

	Tail lamp inspection	/	Daily	C apply dielectric grease to socket when replaced
▲	Air Filter-Main Element	2	Weekly	I C Replace if necessary
▲	Transmission Oil Level	10	Monthly	I change annually
	Battery Terminals	10	Monthly	I C
	Battery fluid level	10	Monthly	I
DL	Brake pad wear	10	Monthly	I
▲	Gear case Oil	10	Monthly	C
		150	annually	R
	Engine Cylinder Head and Cylinder Base Fasteners	25	3 months	I (re-torque required at first service only)
▲	General Lubrication all fittings, pivots, cables, etc.	25	3 months	L
	Engine Oil-Level	/	Daily	I
	Engine Oil Change	30 hrs	500km(312.5mile) or 3 months	R Break-in Service at 1 month. Change oil more often in cold weather use.
▲	Engine breather hose	100 hrs	6 months	I
	Throttle Cable	/	Pre-ride	I
DL	Throttle Cable/Throttle pedal	50 hrs	6 months	A L (Grease M) R if necessary
	Shift linkage	50 hrs	6 months	I A R if necessary
DL	Transmission belt	50 hrs	6 months	I R if necessary
▲	Steering	50 hrs	6 months	I L T if necessary
▲	Front Suspension	50 hrs	6 months	I L T if necessary
▲	Rear Suspension	50 hrs	6 months	I T if necessary

	Spark Plug	100 hrs	12 months	I R if necessary
<span style="border: 1px solid black; padding: 2px;">DL</span>	Ignition Timing	100 hrs	12 months	I Adjust as needed
<span style="border: 1px solid black; padding: 2px;">DL</span>	Fuel System	100 hrs	12 months	Check for leaks at tank, cap, lines, fuel valve, and filter. Replace lines every 2 years.
<span style="border: 1px solid black; padding: 2px;">DL</span>	Fuel Filter	100 hrs	12 months	R
	Radiator	100 hrs	12 months	I R
	Cooling System hoses	50 hrs	6 months	I R if necessary
	Spark arrestor	10 hrs	monthly	C R if necessary
<span style="border: 1px solid black; padding: 2px;">DL</span>	Clutches (drive and Driven)	25 hrs	3 months	I R R if necessary
	Engine mounts	25 hrs	3 months	I T
<span style="border: 1px solid black; padding: 2px;">DL</span>	Valve clearance	100 hrs	12 months	I A
<span style="border: 1px solid black; padding: 2px;">DL</span>	Shift selector box (H/L/R/N)	200 hrs	24 months	Change grease every two years
	Exhaust system	100hrs	12 months	I
<span style="border: 1px solid black; padding: 2px;">DL</span>	Brake fluid Level	/	Pre-ride	I
	Brake fluid	200 hrs	24 months	Change every two years
	Idle Speed	/	As Required	A
<span style="border: 1px solid black; padding: 2px;">DL</span>	Toe adjustment	/	As Required	Periodic inspection, adjust when parts are replaced
	Headlight Aim	/	As Required	Adjust if necessary
<span style="border: 1px solid black; padding: 2px;">▲ DL</span>	Ball joint (A arm- strut)	10 hrs	monthly	I, (for damage, wear, and play) R. Replace if necessary

**LUBRICANT AND FLUID**

	<b>Item</b>	<b>Lube Rec</b>	<b>Method</b>	<b>Frequency</b>
	Engine Oil	SAE 15W/40 SE	Add to proper level on dipstick	Check level daily
	Brake Fluid	DOT 3 Only	Maintain level between fill lines.	As require; change every two years or 200 hours
	Transmission Oil	SEA 80W/90GL5	Add to proper level on dipstick	Change annually or at 100 hours
	Steering system	Grease	Lubricate the pivoting and sliding parts	Every 3 months or 50 hours
	Tie rods	Grease	Grease	Semi-annually
	Shift Linkages	Grease	Locate fittings and Grease	Semi-annually
	Ball joints	Grease	Inspect, Locate fittings and Grease, or replace it if necessary	Semi-annually
	Front/Rear A-arm pivot Shaft	Grease	Locate fitting on pivot shaft and grease with grease gun	Every 3 months or 50 hours
	Throttle Cable	Grease M	Grease, inspect and replace it if necessary	Monthly or 20 hours
	Accelerator pedal and brake pedal	Grease	Grease, inspect	Monthly or 20 hours



※---Check the protective boots for holes or tears. If any damage is found, have them replaced by an authorized dealer.

### 2.1.3 LUBRICATION RECOMMENDATIONS

#### NOTE:

1. More often under severe use, such as wet or dusty conditions.
2. Grease: Light weight lithium-soap grease.
3. Grease M Molybdenum disulfide (MoS<sub>2</sub>) grease (water resistant).
4. When suspension action becomes stiff or after washing.
5. Hours are based on 10 mph(16km/h) average.

## 2.2 THROTTLE PEDAL INSPECTION

### 2.2.1 THROTTLE FREEPLAY

If the throttle pedal has excessive play due to cable stretch or cable misadjustment, it will cause a delay in throttle speed. Also, the throttle may not open fully. If the throttle pedal has no play, the throttle may be hard to control, and the idle speed may be erratic. Check the throttle pedal play periodically in accordance with the Periodic Maintenance Chart and adjust the play if necessary.

### 2.2.2 THROTTLE FREEPLAY INSPECTION



1. Apply the parking brake.
2. Put the gear shift lever in the N (Neutral) position.
3. Start the engine, and warm it up thoroughly.
4. Measure the distance the throttle pedal moves before the engine begins to pick up speed. Free-play should be 1.5 – 3 mm.

#### Adjustment

5. Slide the boot off inline cable adjuster sleeve. Loosen adjuster locknut.
6. Turn adjuster until 1.5 to 3 mm, free play is achieved pedal.

**NOTE:** While adjusting free-play, it is important you flip the throttle lever back and forth.

7. Tighten locknut.



## 2.3 CHOKE ADJUSTMETN

If the choke knob does not stay out when pulled, adjust the choke tension by tightening (clockwise) the chock cable boot until the choke slider freely but stays out when pulled.

If smooth choke operation is not obtainable, inspect choke cable for kinks or sharp bends in routing.



## 2.4 FUEL SYSTEM

### **⚠ WARNING**

Gasoline is extremely flammable and explosive under certain conditions.

- ⚠ Always stop the engine and refuel outdoors or in a ventilated area.
- ⚠ Do not smoke or allow open flames or sparks in or near the area where refueling is performed or where gasoline is stored.
- ⚠ Do not overfill the tank. Do not fill the tank neck.
- ⚠ If you get gasoline in your eyes or swallow gasoline, see your doctor immediately. If you spill gasoline on your skin or clothing, immediately wash it off with soap and water and change clothing.
- ⚠ Never start the engine or let it run in an enclosed area. Gasoline powered engine exhaust fumes are poisonous and can cause loss of consciousness and death in a short time.
- ⚠ Never drain the float bowl when the engine is hot. Severe burns may result.

### 2.4.1 FUEL LINES

1. Check fuel lines for signs of wear, deterioration, damage or leakage. Replace if necessary.
2. Be sure fuel lines are routed properly and secured with cable ties.

#### **CAUTION:**

- Make sure lines are not kinked or pinched.
- Replace all fuel lines every two years.



### 2.4.2 VENT LINES AND ROLL OVER VALVE


- Check fuel tank, oil tank, carburetor, battery and transmission vent lines for signs of wear, deterioration, damage or leakage. Replace every two years.
- Be sure vent lines are routed properly and secured with cable ties.

#### CAUTION:

- Make sure lines are not kinked or pinched.

#### NOTE:


- Make sure the ↑ mark on the roll over valve is upward.



### 2.4.3 FUEL FILTER

The fuel filter should be replaced in accordance with the Periodic Maintenance Chart or whenever sediment is visible in the filter.

1. Remove line clamps at both ends of the filter.
2. Remove fuel lines from filter.
3. Install new filter and clamps onto fuel lines with arrow pointed in direction of fuel flow.
4. Install clamps on fuel line.
5. Start engine and inspect for leaks.




## 2.5 TOE ALIGNMENT

### METHOD: STRAIGHTEDGE OR STRING

Be sure the steering wheel in a straight ahead position.


#### NOTE:

- String should just touch side surface of rear tire on each side of the UTV.
  - The recommended toe alignment is 1/8" to 1/4" (3 to 6mm) toe out.
1. Set the steering wheel in a straight ahead position and hold them in this position.
  2. Measure A and B, B minus A should be 1/16" to 1/8" (1.5 to 3mm).



### **⚠ WARNING**

Always pay attention to tie rods assembly, both ends must screw in same and enough threads length.



## 2.6 BRAKING SYSTEM INSPECTION


The following checks are recommended to keep the braking system in good operating condition. Service life of braking system components depends on operating conditions. Inspect brakes in accordance with the maintenance schedule and before each ride.

- Keep fluid level in the master cylinder reservoir to the indicated level on reservoir.
- Use DOT 3 brake fluid.

#### NOTE:


Use new brake fluid or brake fluid from a sealed container to avoid contamination to system.

- Check brake system for fluid leaks.
- Check brake for excessive travel or spongy feel.
- Check friction pads for wear, damage and looseness.
- Check surface condition of the disc.



### 2.6.1 PAD INSPECTION

Pads should be changed when friction material is worn to 3/64" (1mm).



### 2.6.2 HOSE/FITTING INSPECTION

Check braking system hoses and fittings for cracks, deterioration, abrasion, and leaks. Tighten any loose fittings and replace any worn or damaged parts.

### 2.6.3 ADJUSTING THE BRAKE PEDAL

Check the brake pedal free play. Free-play should be 8 – 12mm.

**Out of specification → Adjust.**

1. Loosen the locknut.
2. Turn brake rod in or out until the correct free play is obtained.

**Turn in: Free-play is increased.**

**Turn out: Free-play is decreased.**

3. Tighten the locknut.

### 2.6.4 ADJUSTING THE PARKING BRAKE

Although the parking brake has been adjusted at the factory, the brake should be checked for proper operation. The mechanical brake must be maintained to be functional enough.


- With the engine off, apply the parking brake lever and attempt to move the UTV.
- If the rear wheels are locked, it is adjusted properly.
- If the wheels are not locked, it must be adjusted.

To adjust (set up) the mechanical parking brake, use the following procedure.

**Note:**

The adjusting on the caliper is for the wear out of the pads.

1. With the engine off, loosen the adjuster on the lever.
2. Loosen the nut of the adjuster on the caliper.
3. Turn the adjuster (bolt) CW (clockwise) by hand till the pad touch the brake disc, turn the adjuster bolt CCW (counterclockwise) by 1/4" to one turn for 10 to 20mm free play at the end of the parking lever.



4. Tighten the nuts securely against the adjusters.
5. Make sure the rear wheels turns freely without dragging.
6. Turn the adjustor (the one on the lever) and apply the lever. While adjusting, it is important you apply the lever back and forth for operation, free play and the locking of the parking position.
7. Make sure the rear wheels turns freely without dragging and parking brake works properly.
8. Field test for parking. It must be capable of holding the laden UTV stationary on an 18% up and down gradient.

A temporary adjusting can also be done to the brake cable on the parking lever side by turn the adjuster (nut) directly. But the adjust range is limited. Always do the procedure 1 to 8 when necessary.

## 2.7 SUSPENSION SPRING RPELOAD ADJUSTMENT

Operator weight and vehicle loading affect suspension spring preload requirements. Adjust as necessary.

### 2.7.1 SUSPENSION

- Compress and release front suspension.
- Damping should be smooth throughout the range of travel.
- Check all front suspension components for wear or damage.
- Inspect from strut cartridges for leakage. Shock spring preload cannot be adjusted, replace if necessary.

### 2.7.2 REAR SUSPENSION

- Compress and release rear suspension.
- Damping should be smooth throughout the range of travel. Check all rear suspension components for wear or damage.
- Inspect shock for leakage.


#### WARNING

- Shock spring preload can be adjusted using the shock wrench.
- Always adjust both shock absorber spring preload to the same setting. Uneven adjustment can cause poor handling and loss of stability.
- Turn the adjuster ① to increase or decrease the spring preload.

Standard position: 3;

Minimum (Soft) position: 1;

Maximum (Hard) position: 5.



## 2.8 WHEELS

- Inspect all wheels for run out of damage.
- Check wheel nuts and ensure they are tight.
- Do not over tighten the wheel nuts.

### 2.8.1 WHEEL REMOVAL


1. Stop the engine, place the transmission in gear and lock the parking brake.
2. Loosen the wheel nuts slightly.
3. Elevate the side of the vehicle by placing a suitable stand under the footrest frame.
4. Remove the wheel nuts and remove the wheel.

### 2.8.2 WHEEL INSTALLATION

1. With the transmission in gear and the parking brake locked, place the wheel in the correct position on the wheel hub. Be sure the valve stem is toward the outside and rotation arrows on the tire point toward rotation.
2. Attach the wheel nuts and tighten them. Install as shown at left for front or rear wheels.
3. Lower the vehicle to the ground.
4. Securely tighten the wheel nuts to the proper torque listed in the table.

### 2.8.3 WHEEL NUT TORQUE SPECIFICATIONS

Bolt Size		Specification	
Front	M12X1.25	59Ft.Lbs	66N·m
Rear	M12X1.25	59Ft.Lbs	66N·m



#### CAUTION:

If wheels are improperly installed it could affect vehicle handling and tire wear.

## 2.9 TIRE PRESSURE

### 2.9.1 TIRE INSPECTION

#### CAUTION:

- Maintain proper tire pressure. Refer to the warning tire pressure decal applied to the vehicle.
- Improper tire inflation may affect UTV maneuverability.
- When replacing a tire always use original equipment size and type and replace in pairs.
- The use of non- standard size or type tires may affect UTV handling and cause machine damage.


Tire Pressure	
front	rear
70kPa/10PSI	100kPa/14PSI

### 2.9.2 TIRE TREAD DEPTH

Always replace tires when tread depth is worn to 1/8" (3mm) or less.

#### **⚠ WARNING**

- Operating an UTV with worn tires will increase the possibility of the vehicle skidding easily with possible loss of control.
- Worn tires can cause an accident.
- Always replace tires when the tread depth measures 1/8" (3 mm) or less.



## 2.10 FRAME , NUTS, BOLTS, FASTENERS

- Periodically inspect the tightness of all fasteners in accordance with the maintenance schedule.
- Check that all cotter pins are in place.
- Refer to specific fastener torques listed in each chapter.



# CHAPTER 3 ENGINE

## 3.1 PREPARATION FOR REMOVAL PROCEDURES

## 3.2 REPLACEMENT PARTS

3.2.1 GASKETS, OIL SEALS AND O-RINGS, BEARING AND OIL SEALS

3.2.2 BEARINGS AND OIL SEALS

## 3.3 PERIODIC INSPECTION AND ADJUSTMENT

3.3.1 AIR FILTER SPARK PLUG

3.3.2 VALVE CLEARANCE ADJUSTMENT

3.3.3 TRANSMISSION OIL INSPECTION

3.3.4 CRANKCASE OIL INSPECTION

## 3.4 ENGINE REMOVAL AND INSTALLATION

3.4.1 CYLINDER HEAD

3.4.2 CYLINDER BODY, PISTON AND PISTON RINGS

3.4.3 V-BELT AND CVT

3.4.4 TRANSMISSION

3.4.5 CRANKCASE AND CRANKSHAFT

3.4.6 MAGNETO

3.4.7 ELECTRIC STARTER OIL PUMP

3.4.8 OIL PUMP

## 3.5 THROTTLE BODY

## 3.6 TIGHTENING TORQUES OF ENGINE MAIN FASTENERS

## 3.7 IGNITION SYSTEM

3.7.1 INSTALLATION INFORMATION

3.7.2 TROUBLE SHOOTING


3.7.3 IGNITION COIL

3.7.4 MAGNETO

### 3.1 PREPARATION FOR REMOVAL

#### PROCEDURES

- Remove all dust and dirt before removal and disassembly.
- Use proper tools and cleaning equipment.
- During machine disassembly, clean all parts and place them in the order of disassembly, which will speed up assembly and allow for the correct installation of all parts.
- Keep all parts away from any source of fire.




### 3.3 REPLACEMENT PARTS

#### 3.3.1 GASKETS, OIL SEALS AND O-RINGS, BEARING AND OIL SEALS

1. Replace all gaskets, seals and O-rings when overhauling the engine. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly and apply grease to the oil seal lips.

#### 3.3.2 BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, apply a light coating of lightweight lithium base grease to the seal lips and oil bearings liberally when installing.



### 3.4 PERIODIC INSPECTION AND ADJUSTMENT

#### 3.4.1 AIR FILTER

1. Remove air filter case cover and 7 fixing screws.
2. Remove 2 filter element fixing screws to check the element for dirt or damage. If so, replace.
3. Install the air filter in the reverse order of removal.


**NOTE:**

As the air filter element is paper-made and contains engine oil, it is not proper to clean it with air.



#### 3.4.2 SPARK PLUG

1. Remove spark plug.
2. Check for burnout, dirt or carbon deposit. Clean them away with a sparkplug cleaner or a cast-steel wire brush.
3. Spark plug gap specification: 0.6-0.7mm.
4. Check for screw thread damage.
5. Such spark plug as NGK (C7HSA, C6HSA) and CHAMPION Z9Y are recommended in replacement.




#### 3.4.3 VALVE CLEARANCE ADJUSTMENT

1. Remove cylinder head cover.



2. Rotate cooling fan to set the mark on camshaft sprocket in Top Dead Center position, that is, to align the timing line on the rotor with the mark on the crankcase.



3. Measure the valve clearance by using a feeler gauge.

**Valve clearance specification:**

**Intake valve 0.08—0.10mm;**

**Exhaust valve 0.10—0.12mm.**




4. To adjust valve clearance, loosen the locknut, turn the adjuster in or out with valve adjusting tool until specified clearance is obtained. Measure the valve clearance once more after the locknut is tightened.

**NOTE:**

Since the crankshaft is equipped with a decompression, the fan cannot be rotated counterclockwise, or it is impossible to adjust the valve.

### 3.4.4 TRANSMISSION OIL INSPECTION

1. Remove the oil level plug.
2. Wipe the oil on the plug and insert it into the filler hole without screwing. The oil level should reach the fourth mark.
3. When replacing the oil, remove transmission case drain plug located on the front cover and drain the oil.



4. Check the O-ring for damage and replace it if necessary.
5. Install the drain plug.
6. Add 80W/90 oil in the recommended amount. Install oil dipstick.
7. The oil capacity of a new engine: 1200ml.
8. The top filling for replacement: 1100ml.

### 3.4.5 CRANKCASE OIL INSPECTION

1. Stand the engine on a level surface.
2. Have the engine run at idle speed for several minutes. Inspect the oil level after the engine is turned off 2-3 minutes.
3. Remove the oil level plug.
4. Wipe the oil on the plug and insert it into the filler hole without screwing. The oil level should reach the fourth mark.



5. When replacing the oil, perform the first two steps and remove the oil strainer to drain the oil.
6. Check the O-ring for damage and replace it if necessary.
7. Install the oil strainer, spring and strainer lid.
8. The oil capacity of a new engine: 900ml;  
The replacement volume: 750ml.
9. After replacement, start the engine and keep it idling for 2-3 minutes and inspect the oil level according to the above instructions.



## 3.4 ENGINE REMOVAL AND INSTALLATION


### 3.4.1 CYLINDER HEAD

#### 3.4.1.1 CAMSHAFT REMOVAL



1. Remove cylinder head cover.




2. Remove camshaft chain pensioner screw and the O- ring.
3. Lock camshaft chain pensioner by turning it clockwise.
4. Rotate fan to have the mark on the camshaft chain in an upward position, which is TDC of engine compression stroke.



5. Remove cylinder head bolts, fixing nuts and gasket of camshaft holder.
6. Loosen 2 nuts (B) 、 Loosen 4 nuts (A). Remove camshaft holder and pins.



7. Remove camshaft.




8. Check for intake and exhaust cam damage.  
Replace when  
intake valve: below 25.75mm;  
exhaust valve: below 25.41mm.
9. Check camshaft bearing for looseness and wear and tear and sprocket for abnormal wear. If so, replace as a whole.

**NOTE:**

Tighten the nuts in a crisscross pattern, each 1/2 or 1/3 turn at a time.

**3.4.1.2 CAMSHAFT HOLDER REMOVAL AND INSTALLATION**

1. Remove rocker arm shafts by using a bolt of 5mm. Remove one-way exhaust valve and rocker arm.
2. Check camshaft holder, rocker arms and rocker arm shafts for abnormal wear and tear.



3. Measure the inside diameter of rocker arm shaft hole in camshaft holder.  
Limit: 10.10mm.
4. Measure the inside diameter of rocker arm hole.  
Limit: 10.10mm.
5. Measure the diameter of rocker arm shaft.  
Limit: 9.91mm.




### 3.4.1.3 CYLINDER HEAD REMOVAL

1. Remove the pipe composition of throttle body.




2. Remove fan cover composition.

3. Remove upper and lower shrouds.



4. Remove cylinder head.




5. Remove dowel pin, cylinder head gasket and take out chain guide.


6. Remove the gasket on cylinder surface.



7. Take out valve seat, lock plate, spring, oil seal and valve by using a compressor.




8. Clean off carbon deposits in the combustion chamber.




9. Check spark plug, valve guide and their surrounding areas for cracks.


10. Check contact face evenness.  
Limit: 0.05mm.



11. Measure valve spring free length.  
Limit:  
inner spring: 31.2mm.  
outer spring: 34.1mm.



12. Check valve stem bend and check for burnout.  
Clean carbon deposits off its surface.
13. Measure valve stem diameter.  
Limit: 4.9mm.
14. Clean off carbon deposits in valve guide.
15. Eliminate carbon deposits from valve seat.



16. Measure valve guide inside diameter.  
Limit:  
Intake: 5.08mm;  
Exhaust: 5.10mm.





17. Install cylinder head in the reverse order of removal.

**NOTE:**


- Make sure the contact cylinder surfaces are not scratched.
- Make no other objects fall into the crankcase.
- The cylinder head gasket must not be reused.
- Be sure not to scratch the valve seat contact face.

**3.4.2 CYLINDER BODY, PISTON AND PISTON RING**


1. Remove cylinder body.



2. Remove cylinder gasket dowel pin. Eliminate carbon deposits from gasket.



3. Remove piston pin circlip, piston pin and piston.  
4. Remove piston ring. Eliminate the carbon deposits from the piston ring grooves and rings.



5. Position piston ring. Measure the gap between piston ring and ring groove.

Limit:

first ring: 0.09mm;

2<sup>nd</sup> ring: 0.09mm.




6. Measure piston pin bore diameter.

Limit: 15.04mm.

7. Measure piston pin outside diameter.


Limit: 14.96mm.



8. Measure piston outside diameter from an angle of 90° to piston pin bore, in a position some 9mm from piston bottom.



9. Check cylinder inside surface for scratches and wear. Measure cylinder inside diameter from an angle of 90° to piston pin and in upper, middle and lower three positions.



10. Check cylinder body evenness.

Limit: 0.05mm.

Install cylinder in the reverse order of removal.




**NOTE:**


- Make sure the circlip does not fall into the crankcase.
- Be sure to keep the piston ring undamaged.
- Make sure to install the piston rings so that the slots are staggered by 120° and the sides with letters on are located upwards.

### 3.4.3 V-belt AND CVT

1. Remove left crankcase cover.



2. Remove drive face.




3. Take out V-belt.

4. Check belt for cracks, wear, scaling or chipping.

5. Measure V-belt width.


limit : 19.0mm.



6. Remove sliding sheave.



7. Remove movable cams.



8. Remove clutch weights.



9. Check weights wear.  
10. Measure weight outside diameter.  
Limit : 17.44mm.




11. Measure sliding sheave inside diameter.  
Limit : 24.06mm.




12. Check collar wear.  
13. Measure collar outside diameter.  
Limit : 23.94mm, replace.


14. Remove clutch.



15. Check clutch disk wear.  
Limit : 125.5mm.



16. Check spacer wear.  
17. Measure its thickness.  
Limit : 1.5mm.




18. Remove clutch assembly.




19. Remove clutch locknut.


20. Take out secondary fixed sheave and sliding sheave.



21. Measure compression spring free length.  
Limit: 163mm.



22. Check secondary sliding sheave wear.  
23. Measure its shaft inside diameter.  
Limit : 34.06m.



23. Check secondary fixed sheave wear.  
24. Measure its shaft diameter.  
Limit : 33.94mm.  
Install them in the reverse order of removal.




- NOTE:**  
Never smear grease to the V-belt, secondary sheave and clutch.




### 3.4.4 TRANSMISSION

#### 3.4.4.1 TRANSMISSION DISASSEMBLY


1. Remove transmission case drain plug located on the front cover and drain the oil.



2. Remove transmission case fixing bolts.




3. Remove the bolts on the shift cover and remove the shift cover. Remove shift cam, shift limit spring, and shift shaft, etc.




4. Remove the left cover of the transmission.




5. Remove the intermediate shaft assembly, the secondary axis assembly, and the output axis assembly in turn.



6. Remove the spindle assembly and countershaft assembly etc.



7. Prior to reinstalling the transmission make sure the mating surfaces are clean and dry, and shafts are fully seated in transmission case. Apply silicon glue to mating surfaces.



8. Install new input shaft seal.

9. Install drain plug with a new sealing washer. Torque drain plug to 14.5 ft.lb. (20N·m).

10. Add 80W/90 oil in the recommended amount. Install oil dipstick.


11. Between speed sensor and gear top the distance is 1.0 ~ 1.5 mm, adjust the sensor of the screw into the access to the gear, and then go toward outside revolves fixed nut.




### 3.4.5 CRANKCASE AND CRANKSHAFT

1. Remove chain guide fixing bolt to take out chain.


2. Remove driven gear from crankshaft and inspect gear for wear.




3. Remove crankcase fixing bolts and separate the left crankcase from the right one.



4. Remove gasket fitting pin.




5. Take out crankshaft and timing chain.




6. Clean gasket on crankcase contact face.

**NOTE:**


Make sure the contact faces are not scratched to avoid oil leakage.




7. Remove oil seal from crankcase. Inspect oil seal for wear.



8. Measure connecting rod big end side clearance.  
Limit : 0.55mm.



9. Measure big end crankpin diametral clearance.  
limit: 0.55mm.



10. Measure small end orifice inside diameter.  
limit: 15.06mm.

11. Inspect crankshaft bearings for abnormal noise and looseness. If so, replace.

Install them in the reverse order of removal.

**NOTE:**



Be sure to drain crankcase oil before crankcase removal.

**3.4.6 MAGNETO**


1. Remove magneto cover fixing bolts and screws to dismount magneto cover. Inspect cover for damage and cracks.

2. Remove 4 fixing bolts to take out fan. Inspect fan for blade aging and cracks. If so, replace.

3. Remove magneto flywheel locknut.





4. Take out magneto rotor using the flywheel puller. Inspect magneto flywheel tapered orifice and key way for wear, scratches and cracks. If so, replace.



5. Remove stator fixing screw to take out stator. Install it in the reverse order of removal.

**NOTE:**

As there is magnetism inside the magneto rotor, make sure no metal object is taken in and the inside of the rotor is cleaned out before installation.




**3.4.7 ELECTRIC STARTER**


1. Remove starter clutch.




2. Remove idler gear and idle gear shaft.



3. When turning the starter wheel gear counterclockwise, it should turn freely. When turning the starter wheel gear clockwise, it should be engaged.




4. Inspect clutch wheel gear for abnormal wear. If so, replace it with a new one.




5. Measure gear wheel orifice inside diameter. If it goes beyond the limit of 32.06mm, replace.

6. Inspect needle roller bearing for wear. Check if needle roller turns freely in its holder. If it works improperly, replace it with a new one.



7. Take spring, spring sleeve and roller out of clutch outer race. Inspect roller for wear, spring for distortion and out race for wear. If there appears anything abnormal, replace.
8. Measure clutch disk hub outside diameter.  
Limit : 27.94mm.




9. Inspect idler gear and idle gear shaft for abnormal wear. If so, replace.
10. Measure idle gear shaft orifice inside diameter.  
Limit : 10.05mm.
11. Measure idle gear shaft outside diameter.  
Limit : 9.94mm.  
Install them in the reverse order of removal.




**3.4.8 OIL PUMP**

1. Remove bolts to dismount right crankcase cover.


2. Remove gasket and dowel pin. Remove clutch.




3. Remove oil pump cover.




4. Remove nut to take out oil pump sprocket and chain. Inspect them for abnormal wear. If so, replace.



5. Measure tip clearance between rotors and pump housing.  
Limit : 0.2mm.



6. Inspect oil pump inner and outer rotors for abnormal wear. If so, replace the oil pump assembly.



7. Fasten oil pump with screws after assembling.  
Install oil pump in the reverse order of removal.

#### **NOTE:**

Be sure to point the arrow on the oil pump to the direction of crankshaft in installation and infuse some oil into the pump beforehand.

### **3.5 THROTTLE BODY**

1. Please replace if damage.



**3.6 TIGHTENING TORQUES OF ENGINE MAIN FASTENERS**

Description	Thread size	Tightening torque (N•m)
Cylinder head bolt	M6	9
Oil filter screen cover bolt	M30	15
Exhaust pipe nut	M6	9
Camshaft seat nut	M8	20
Valve adjuster lock nut	M5	9
Cam chain tensioner bolt	M6	10
Transmission case drain bolt	M8	19
Clutch drive plate nut	M12	55
Clutch driven disk nut	M12	55
Spark plug	M10	12
Driven clutch wood ruff key nut	M22	95
Case (right & left) and case cover (right & left)	M6	9
Transmission output gear bolt	M8	30

### 3.7 IGNITION SYSTEM

#### 3.7.1 INSTALLATION INFORMATION OPERATING POINTS

- Check ignition system in accordance with the troubleshooting procedure i.
- Poor contact may be the cause of many ignition system faulty cases. Check all terminal connections to be sure they are clean and tight whenever troubleshooting an electrical problem.
- Make sure spark plug heat range is correct. Using incorrect spark plug will result in improper engine operation or spark plug damage.
- Peak voltage is used as reference point in tests. Record coil resistance tests.

#### REFERENCE STANDARD

item		Standard value	
Specific spark plug		A7TC	
spark plug gap		0.6-0.7mm	
spark plug angle	Maximum advance in "F" position	$13^{\circ} \pm 1^{\circ}$ (1700r/min)	
Ignition	Primary coil	0.1-1.0 $\Omega$	
	Secondary	With cap	7-9k $\Omega$
		Without cap	3-4k $\Omega$
Pickup coil resistance(20 $^{\circ}$ C)		80-160 $\Omega$	
Pickup coil peak voltage		Over 2.1V	

#### 3.7.2 TROUBLE SHOOTING

##### High Tension Voltage Too Low

- Crankshaft revolution too low or battery voltage too low
- Ignition system wiring loose
- Faulty Ignition coil
- Faulty pickup coil

##### High Tension Voltage Intermittent




- Faulty main switch
- Faulty pickup coil
- Poor high tension lead terminal connection


##### High Tension Voltage Normal but No Spark

- Faulty spark plug
- Faulty spark plug cap

##### No High Tension Voltage

- Faulty main switch
- Faulty Ignition coil

<b>No or Intermittent High Tension Voltage</b>	
<ul style="list-style-type: none"> <li>Faulty Ignition coil</li> </ul>	
<b>3.7.3 IGNITION COIL</b>	
<b>Removal Steps</b>	
<ul style="list-style-type: none"> <li>Remove the middle box.</li> </ul>	
<ul style="list-style-type: none"> <li>Remove the spark plug cap.</li> </ul>	
<ul style="list-style-type: none"> <li>Disconnect the wires, remove ignition coil</li> </ul>	
<ul style="list-style-type: none"> <li>Jam nuts and remove the ignition coil.</li> </ul>	
<b>Inspection</b>	
<ul style="list-style-type: none"> <li>Check the ignition coil circuit.</li> </ul>	
<ul style="list-style-type: none"> <li>The spark advance angle does not need to be adjusted.</li> <li>If spark advance is abnormal, check the CDI, pickup coil or magneto.</li> <li>Replace the ignition coil if necessary.</li> </ul>	
<ul style="list-style-type: none"> <li>Test the primary coil resistance, the standard value of which should be 0.1-1.0Ω.</li> </ul>	
<ul style="list-style-type: none"> <li>Test the secondary coil resistance from spark plug cap negative terminals, the standard value of which should be 7-9 kΩ (with cap) and 3-4 kΩ (without cap).</li> </ul>	
<ul style="list-style-type: none"> <li>Coil test using after market spark tester.</li> </ul>	
<ul style="list-style-type: none"> <li>Perform the following inspection in accordance with the operating instructions in the Manual.</li> </ul>	
<ul style="list-style-type: none"> <li>Set the ignition coil tester switch in 12V and connect the tester to the ignition coil.</li> </ul>	
<ul style="list-style-type: none"> <li>Turn the switch to the ON position to check spark frequency from the inspection door.</li> </ul>	
<ul style="list-style-type: none"> <li>In good condition: Sparking continuously</li> </ul>	
<ul style="list-style-type: none"> <li>In faulty condition: Sparking abnormally</li> </ul>	

<b>3.7.4 MAGNETO</b>	
<b>Pickup Coil Inspection</b>	
<ul style="list-style-type: none"> <li>● This test is to be conducted with the stator mounted in the engine.</li> </ul>	
<ul style="list-style-type: none"> <li>● Remove the cover.</li> </ul>	
<ul style="list-style-type: none"> <li>● Disconnect the magneto.</li> </ul>	
<ul style="list-style-type: none"> <li>● Test the pickup coil resistance between the blue /yellow and the green lead terminals, whose standard value is 80-160Ω.</li> </ul>	
<ul style="list-style-type: none"> <li>● Dismounting the magneto.</li> </ul>	
<b>Charging Coil Inspection(for MINI ATV100/150)</b>	
<ul style="list-style-type: none"> <li>● Test the charging coil resistance between the black/red and the green lead terminals, whose standard value is 450-550Ω.</li> </ul>	
<b>Spark Advance Angle Inspection</b>	



# CHAPTER 4 CHASSIS

## WARNING

The parts of different types/ variants/ versions maybe un-interchangeable, even some parts have almost same appearance. Always refer to Parts Manual of each CUV model for spare parts information and service.

### 4.1 FRONT A-ARM REPLACEMENT

### 4.2 REAR A-ARM REPLACEMENT

### 4.3 REAR STABILIZER BAR REMOVAL/INSTALLATION

### 4.4 FRONT STRUT REPLACEMENT

### 4.5 FRONT STRUT BALL JOINT REPLACEMENT


### 4.6 BOX REMOVAL/INSTALLATION

#### 4.6.1 BOX REMOVAL

#### 4.6.2 BOX INSTALLATION

### 4.7 STEERING ASSEMBLY REMOVAL/INSTALLATION

## 4.1 FRONT A-ARM REPLACEMENT



1. Elevate and safely support vehicle with weight removed from front wheel(s).
2. Remove cotter pin from ball joint stud at wheel end of A- arm and loosen nut until it is flush with end of stud.
3. Using a soft face hammer, tap nut to loosen A- arm from bolt. Remove nut and A-arm from hub strut assembly.
4. Loosen and remove two bolts on A-arm, and remove A-arm.
5. Examine A-arm bushing. Replace if worn or tore. Discard hardware.
6. Install new A-arm assembly onto vehicle frame. Install new bolts and new nuts.

### NOTE:


Tighten the nuts only finger-tighten at this time. They will be tightened to the final torque after the front wheels are installed and the vehicle is on the ground. DO NOT reuse old bolts. Serious injury or death could result if fasteners come loose during operation.

7. Attach A-arm to strut assembly. Tighten ball joint nut to 25 ft. lbs. (35 Nm). If cotter pin holes are not aligned, tighten nut slightly to align. Install a new cotter pin with open ends toward rear of machine. Bend both ends in opposite directions around nut.
8. Install hubs, calipers and wheels, lower the vehicle to the ground. Apply Loctite™ 242 to screw threads of the A arm bolts and torque bolts to 37-44 ft. lbs. (50-60 Nm).



Upon A-arm installation completion, test vehicle at low speeds before putting into regular service.

### 4.2 REAR A-ARM REPLACEMENT



1. Elevate and safely support vehicle with weight removed from the rear wheel(s).



2. Remove the wheel nuts and wheel.

**NOTE:** To ease the removal of the spindle bolt, remove the hub cap and loosen the spindle bolts before removing the wheel.



3. Remove the hub cap, cotter pin, spindle bolt, and washer.



4. Remove the brake caliper. Suspend the brake caliper from the frame with a wire.

**NOTE:** Do not let the brake caliper hang from the brake line or damage may occur.



5. Loosen two bolts that secure the rear knuckle to the A-arm. Remove the rear knuckle assembly by sliding it off of the axle.

6. Remove the bolt that secures the shock and coil to the lower A-arm.
7. Loosen the bolt that secure the A-arm to frame by alternating each about 1/3 of the way until A-arm can be removed. Perform this procedure on the upper A-arm.
8. Examine the A-arm bushing and A-arm shaft. Replace if worn. Discard hardware.
9. Remove the bottom stabilizer bar nut.
10. Loosen two bolts that secure the A –arm bushing to frame by alternating each about 1/3 of the way until the A-arm can be removed. The lower A-arm should now be free to remove.
11. Insert new A-arm bushings and new A-arm shaft into new A-arm.
12. Install new A-arm assembly onto vehicle frame. Apply Loctite™ 242 to screw threads of the A arm bolts and torque bolts to 44 ft. lbs. (60 Nm).

** WARNING**


DO NOT reuse old bolts. Serious injury or death could result if fasteners come loose during operation.

13. Attach A-arm to rear knuckle. Tighten upper and lower bolts to 44 ft. lbs. (60 Nm).
14. Install the shock and tighten shock bolt to 32 ft.lbs. (44 Nm).
15. Install the stabilizer and tighten nut to 40 ft.lbs. (56 Nm).
16. Re-install wheel and caliper.

** WARNING**

Upon A-arm installation completion, test vehicle at low speeds before putting into regular service.


### 4.3 REAR STABILIZER BAR REMOVAL/INSTALLATION



1. Elevate and safely support vehicle with weight removed from the rear wheel(s).
2. Remove the rear wheel to gain access to the stabilizer bar, each side.
3. Remove the stabilizer bar nut from the lower A-arm, each side.
4. Remove the two bolts that secure the stabilizer bar to the main frame, each side.
5. Remove the stabilizer from the frame.
6. Inspect the stabilizer bar. Inspect the bushings and replace if needed.
7. Inspect the stabilizer joint and replace if needed.
8. Reverse the procedure for installation. Torque the stabilizer bolts to 23 ft.lbs (32 Nm).



## 4.4 FRONT STRUT REPLACEMENT



1. Hold strut rod with wrench and remove top nut.
2. Compress spring.
3. Remove upper strut pivot assembly.
4. Remove coil spring and collapse strut body.
5. Remove two pinch bolts from strut body.
6. Remove strut body.
7. Install front shock cartridge until bottomed in strut casting.
8. Install pinch bolts with clamp(s). Torque pinch bolts to 15ft.lbs.(21Nm).
9. Reassemble spring and top pivot assembly. Be sure all parts are installed properly and seated fully.
10. Torque strut rod nut to specification. Do not over torque nut.  
Strut Rod Nut Torque:15 ft. lbs. (21 Nm)

## 4.5 FRONT STRUT BALL JOINT REPLACEMENT





1. Loosen front wheel nuts.
2. Elevate and safely support CUV under footrest / frame area.

**CAUTION:** Serious injury may result if CUV tips or falls. Be sure CUV is secure before beginning this service procedure.

3. Remove wheel nuts and wheels.
4. Remove cotter pin from ball joint.
5. Remove castle nut and separate A- arm from ball joint stud.
6. Remove screws and ball joint mounting bracket.
7. Using ball joint cup removal/installation toolkit, remove ball joint cup from strut housing.

Refer to photos at right.


- Install puller guide (1) .
  - Thread bolt (2) with nut (3) onto ball joint stud as shown .
  - Hold bolt (2) and turn nut (3) clockwise until ball joint is removed from strut housing.
8. To install new ball joint cup.
    - Insert new ball joint into driver(installation toolkit).
    - Drive new ball joint cup into strut housing until fully seated.



9. Apply Loctite 242 (blue) to threads of mounting bracket new screws.  
Torque screws to 8 ft.lbs. (11 Nm).

10. Install A- arm on ball joint cup and torque castle nut to 25 ft. lbs. (35 Nm).

11. Reinstall cotter pin with open ends toward rear of machine.



## 4.6 BOX REMOVAL/INSTALLATION

### 4.6.1 BOX REMOVAL

1. Disconnect the license light coupler.
2. Lift the box into the dump position.
3. Remove the box shock pin from the frame(both sides).
4. Remove the shocks from the shock brackets. Let the shocks fully extend.

**CAUTION:** Safely support the box during the rest of the removal process. The box is not as stable with the shocks removed.

5. Remove the cotter pin from the hinge pin.
6. Remove the hinge pin (both sides).

**CAUTION:** Safely support the box during the rest of the removal process. The box is not as stable with the hinge pin removed.

7. With the hinge pins removed, remove the box from the frame. Two people maybe needed to remove the bed from the frame.


**CAUTION:** Use caution when removing the box. It is recommended to have two people to carefully remove the box from the frame.

### 4.6.2 BOX INSTALLATION

1. Place the box onto the frame. Align the hinges of the box with the frame.
2. Install the box hinges (both sides).
3. Secure the box hinges with the cotter pins(both sides).
4. With the hinges installed, decompress the box shocks and place them into the shock brackets on the frame (both sides).
5. Secure the box shocks with the shock pin(both sides).
6. Lower the box and secure the latch.
7. Connect the taillight coupler.



## 4.7 STEERING ASSEMBLY REMOVAL/INSTALLATION



1. With the steering wheel cover bolts removed, remove the steering wheel cover and the steering wheel.
2. With the steering wheel holder nut removed, remove the steering wheel holder.
3. Remove the steering column bolts.
4. Remove the upper of the steering column.
5. Remove the cotter pins and the tie rod end bolts (both sides).
6. With the cover bolts removed, remove the steering assembly and the lower of the steering column.
7. Reverse the procedure for installation.



# CHAPTER 5 FINAL DRIVE

## WARNING

The parts of different types/ variants/ versions maybe un-interchangeable, even some parts have almost same appearance. Always refer to Parts Manual of each CUV model for spare parts information and service.

### **5.1 WHEEL, HUB, AND SPINDLE TORQUE TABLE**

### **5.2 FRONT HUB EXPLODED VIEW**

5.2.1 FRONT HUB REMOVAL/INSPECTION

5.2.2 FRONT HUB INSTALLATION

5.2.3 FRONT HUB BEARING REPLACEMENT

### **5.3 REAR HUB EXPLODED VIEW**

5.3.1 REAR HUB AND KNUCKLE REMOVAL / INSPECTION

5.3.2 REAR HUB AND KNUCKLE INSTALLATION

5.3.3 REAR DRIVE SHAFT REMOVAL


5.3.4 REAR DRIVE SHAFT INSTALLATION

### 5.1 WHEEL , HUB , AND SPINDLE TORQUE TABLE

Item	Specification
Front Wheel Nuts	59 Ft.Lbs 66 Nm
Rear Wheel Nuts	59 Ft.Lbs 66 Nm
Front Hub Nut on Spindle/ outer CV joint	101 Ft.Lbs 137 Nm
Rear Hub Retaining Nut	101 Ft.Lbs 137 Nm

Refer to exploded views and text for torque values of other fasteners.

**CAUTION:** Locking nuts, and bolts with pre-applied locking agent should be replaced if removed. The self-locking properties of the nut or bolt are reduced or destroyed during removal.




## 5.2 FRONT HUB EXPLODED VIEW

### 5.2.1 FRONT HUB REMOVAL/INSPECTION

1. Elevate front end and safely support machine under footrest/frame area.

**CAUTION:** Serious injury may result if machine tips or falls. Be sure machine is secure before beginning this service procedure. Wear eye protection when removing bearings and seals.

2. Check bearings for side play by grasping the tire/Wheel firmly and checking for movement.
3. Grasp the top and bottom of the tire. The tire should rotate smoothly without binding or rough spots.



4. Remove wheel nuts and wheel.
5. Remove the two brake caliper mounting bolts.


**CAUTION:** Do not hang the caliper by the brake line. Use wire to hang the caliper to prevent possible damage to the brake line.

6. Remove hub cap, cotter pin, front spindle nut, and washer.
7. Rotate each bearing by hand and check for smooth rotation. Visually inspect bearing for moisture, dirt, or corrosion, or roughness is evident.



### 5.2.2 FRONT HUB INSTALLATION

1. Inspect the hub strut bearing surface for wear or damage.
2. Apply grease to drive axle spindle.
3. Install spindle through the backside of the hub strut. Install the hub onto the spindle.
4. Install spindle nut and tighten to 101 ft.lbs (137 Nm).
5. Install a new cotter pin. Tighten nut slightly if necessary to align cotter pin holes.
6. Rotate wheel and check for smooth operation. Bend both ends of cotter pin around end of spindle in different directions. Install hub cap.



7. Rotate hub. It should rotate smoothly without binding or rough spots or side play.
8. Install brake caliper using new bolts. (Apply Loctite™ 242 to threads) Tighten bolts to 18 ft.lbs (24Nm).

**CAUTION:** New bolts have a pre-applied locking agent which is destroyed bolts upon removal. Always use new brake caliper mounting bolts upon assembly.

9. Install wheel and wheel nuts and tighten evenly in a cross pattern to specified torque.




### 5.2.3 FRONT HUB BEARING REPLACEMENT


1. Remove outer snap ring.
2. Form the back side, tap on the outer bearing race with a drift punch in the reliefs as shown.
3. Drive bearing out evenly by tapping on outer race only. Once bearing is at bottom of casting, support casting on outer edges so bearing can be removed.
4. Inspect bearing.

**NOTE:** Due to extremely close tolerances and minimal wear, the bearings must be inspected visually, and by feel. While rotating bearings by hand, inspect for rough spots, discoloration, or corrosion. The bearings should turn smoothly and quietly, with no detectable up and down movement and minimal movement sideways between inner and outer race.

5. Inspect bearing housing for scratches, wear or damage. Replace housing if damaged.



### 5.3 REAR HUB EXPLODED VIEW



#### 5.3.1 REAR HUB AND KNUCKLE REMOVAL / INSPECTION

1. Elevate rear end and safely support machine under main frame area.

**CAUTION:** Serious injury may result if machine tips or falls. Be sure machine is secure before beginning this service procedure. Wear eye protection when removing bearings and seals.

2. Check bearings for side play by grasping the tire/Wheel firmly and checking for movement. Grasp the top and bottom of the tire. The tire should rotate smoothly without binding or rough spots.
3. Remove wheel nuts and wheel.
4. Remove the two brake caliper attaching bolts.

**CAUTION:** Do not hang the caliper by the brake line. Use wire to hang the caliper to prevent possible damage to the brake line.

5. Remove hub cap, cotter pin, front spindle nut, and washer.
6. Remove the upper and lower control arm bolts.
7. Slide the rear hub and knuckle from the rear drive axle.
8. Inspect the rear hub and knuckle assembly by hand for smoothness and side to side movement, replace as needed.



### 5.3.2 REAR HUB AND KNUCKLE INSTALLATION

1. Start the rear hub and knuckle assembly onto the drive shaft.
2. Align the bottom of knuckle and lower control arm. Secure with the lower control arm bolt.
3. With the driveshaft placed in the knuckle, align the knuckle with the top control arm. Secure with the upper control arm bolt.
4. Torque the top and bottom A-arm bolts as shown in the photo.
5. Install the washer and the spindle retainer nut.
6. Install the wheel and wheel nuts. Torque wheel nuts to 59 ft.lbs. (66 Nm).
7. Lower the vehicle. Torque the spindle retaining nut to 101 ft.lbs. (137 Nm). Install a new cotter key and the hub cap.
8. Install brake caliper using new bolts. (Apply Loctite™ 242 to threads) Tighten bolts to 18 ft.lbs (24 Nm).



### 5.3.3 REAR DRIVE SHAFT REMOVAL

- Repeat of the steps in the “REAR HUB AND KNUCKLE REMOVAL” section.
- “KNUCKLE REMOVAL” section. xpulling the hub and knuckle assembly outward and down.
- Pull the rear drive axle straight out of the frame. Use short sharp jerks to free the circlip from the gearcase. The circlip holds the axle in the gearcase.
- Inspect the axle splines and cv boots for any damage.



### 5.3.4 REAR DRIVE SHAFT INSTALLATION

1. Install a new circlip onto the rear drive shaft. Apply Anti-Seize Compound onto the rear driveshaft splines (both ends).
2. Reinstall the rear driveshaft into the rear gearcase. Be sure the circlip is securely fit into the rear gearcase. Use a rubber mallet to tap on the outboard end of the driveshaft if necessary.
3. Slide the rear drive axle into the knuckle.

4. Lift knuckle into place and install bolt to upper and lower control arm. Torque bolt to 44 ft.lbs (60 Nm).
5. Install the washer and the spindle retainer nut.
6. Install the wheel and wheel nuts. Torque wheel nuts to 59 ft.lbs. (66 Nm).
7. Lower the vehicle. Torque the spindle retaining nut to 101 ft.lbs. (137 Nm). Install a new cotter key and the hub cap.
8. Install brake caliper using new bolts. (Apply Loctite™ 242 to threads) Tighten bolts to 18 ft.lbs (24 Nm)





# CHAPTER 6 BRAKES

## WARNING

The parts of different types/ variants/ versions maybe un-interchangeable, even some parts have almost same appearance. Always refer to Parts Manual of each ATV model for spare parts information and service.

**NOTE:** Also See Chapter 2 for Maintenance Information.

### **6.1 SPECIFICATIONS**

### **6.2 TORQUE**

### **6.3 BRAKE SYSTEM SERVICE NOTES**

### **6.4 BURNISHING PROCEDURE**

### **6.5 BRAKE BLEEDING-FLUID CHANGE**

### **6.6 PARKING BRAKE AND BRAKE LINE INSPECTION**

### **6.7 PARKING BRAKE ADJUSTMENT**

#### 6.7.1 PARKING BRAKE INSPECTION

#### 6.7.2 PARKING BRAKE ADJUSTMENT

#### 6.7.3 PARKING BRAKE REAR CALIPER REMOVAL / INSTALLATION

### **6.8 PARKING BRAKE REAR CALIPER REMOVAL/INSTALLATION**

#### 6.8.1 REMOVAL

#### 6.8.2 INSPECTION

#### 6.8.3 INSTALLATION

### **6.9 FRONT DISC INSPECTION / REMOVAL / REPLACEMENT**

#### 6.9.1 INSPECTION

#### 6.9.2 REMOVAL/ REPLACEMENT

### **6.10 FRONT CALIPER INSPECTION / REMOVAL / REPLACEMENT**

#### 6.10.1 REMOVAL

#### 6.10.2 INSPECTION

#### 6.10.3 INSTALLATION

### **6.11 REAR BRAKE PAD REMOVAL/ INSPECTION / INSTALLATION**

#### 6.11.1 REMOVAL

#### 6.11.2 INSPECTION

#### 6.11.3 INSTALLATION

### **6.12 REAR CALIPER REMOVAL/ INSPECTION / INSTALLATION**

### **6.13 REAR BRAKE DISC REMOVAL/ INSPECTION/ INSTALLATION**

#### 6.13.1 INSPECTION

#### 6.13.2 INSTALLATION

## 6.1 SPECIFICATIONS

Front Brake Caliper		
Item	Standard	Service Limit
Brake Pad Friction material Thickness	0.157"/ 4mm	0.04"/ 1mm
Brake Disc Thickness	0.150- 0.164"/3.810- 4.166mm	0.140"/ 3.556mm
Brake Disc Thickness Variance Between Measurements	-	0.002 " / 0.051m m
Brake Disc Run out	-	0.005 " / 0.127mm
Rear Brake Caliper		
Item	Standard	Service Limit
Brake Pad Friction material Thickness	hydraulic	0.157"/ 4mm
	Hydraulic with mechanics park	0.236"/ 6mm
	mechanics park	0.197"/ 5mm
Brake Disc Thickness	0.177-0.187"/4.496-4.750m m	0.167"/4.242mm
Brake Disc Thickness Variance Between Measurements	-	0.002 " / 0.051mm
Brake Disc Run out	-	0.05 0.127mm

## 6.2 TORQUE

Item	Torque (ft. lbs. except where noted*)	Torque (Nm)
Front Caliper Mounting Bolts	18.0	25
Rear Caliper Mounting Bolts	18.0	25
Front Brake Disc	18.0	25
Rear Brake Disc	18.0	25

## 7.3 BRAKE SYSTEM SERVICE NOTES

- It is strongly recommended always change the caliper and (or) the master cylinder as an assembly. The parts inside maybe not interchangeable due to different brake manufactures and (or) different brake type.
- Do not over – fill the master cylinder fluid reservoir.
- Make sure the brake lever and pedal returns freely and completely.
- Check and adjust master cylinder reservoir fluid level after pad service.
- Make sure atmospheric vent on reservoir is unobstructed.
- Adjust foot brake after pad service.

- Test for brake drag after any brake system service and investigate cause if brake drag is evident.
- Make sure caliper moves freely on guide pins (where applicable).
- Inspect caliper piston seals for foreign material that could prevent caliper pistons from returning freely.
- Perform a brake burnishing procedure after install new pads to maximize service life.
- DO NOT lubricate or clean the brake components with aerosol or petroleum products. Use only approved brake cleaning products.

## 7.4 BURNISHING PROCEDURE

Brake pads (both hydraulic and mechanical) must be burnished to achieve full braking effectiveness. Braking distance will be extended until brake pads are properly burnished. To properly burnish the brake pads, use the following procedure.

1. Choose an area large enough to safely accelerate the CUV to 40 km/h (24 mph ) and to brake to a stop.
2. Using hi gear, accelerate to 40 km/h (24 mph); then compress brake lever (pedal) to decelerate to 0-8km/h (5 mph).
3. Repeat procedure on each brake system 20 times until brake pads are burnished.
4. Adjust the mechanical parking brake (if necessary).
5. Verify that the brake light illuminates when the hand lever is compressed or the brake pedal is depressed.

### WARNING

Failure to properly burnish the brake pads could lead to premature brake pad wear or brake loss. Brake loss can result in severe injury.

## 7.5 BRAKE BLEEDING-FLUID CHANGE

**NOTE:** When bleeding the brakes or replacing the fluid always start with the caliper farthest from the master cylinder.

### **CAUTION:**

Always wear safety glasses.


### **CAUTION:**

Brake fluid is highly corrosive. Do not spill brakes fluid on any surface of the CUV.

This procedure should be used to change fluid or bleed brakes during regular maintenance.

1. Clean reservoir cover thoroughly.

2. Remove cover from reservoir.



3. If changing fluid, remove old fluid from reservoir with a brake fluid pump or similar tool.

4. Add brake fluid up to the indicated MAX level on the reservoir.

**DOT 3 Brake Fluid**

5. Begin bleeding procedure with the caliper that is farthest from the master cylinder. Install a box end wrench on the caliper bleeder screw. Attach a clean, clear hose to the fitting and place the other end in a clean container. Be sure the hose fits tightly on the fitting.

6. Slowly pump foot pedal until pressure builds and holds.

7. Hold brake pedal on to maintain pedal pressure, and open bleeder screw. Close bleeder screw and release foot pedal.

**NOTE:** Do not release foot pedal before bleeder screw is tight or air may be drawn into master cylinder.

8. Repeat procedure until clean fluid appears in bleeder hose and all air has been purged. Add fluid as necessary to maintain level in reservoir.

**CAUTION:**

Maintain at least 1/2 "(13mm of brake fluid in the reservoir to prevent air from entering the master cylinder.


9. Tighten bleeder screw securely and remove bleeder hose.

10. Repeat procedure steps 5- 9 for the remaining calipers.
11. Add brake fluid to MAX level inside reservoir.

Master Cylinder Fluid Level Between the MIN line and the MAX line of reservoir.

1. Install master cylinder reservoir cover.
2. Field test machine at low speed before putting into service. Check for proper braking action and pedal reserve. With pedal firmly applied, pedal reserve should be no less than 1/2 " (1.3cm ).
3. Check brake system for fluid leaks and inspect all hoses and lines for wear or abrasion. Replace hose if wear or abrasion is found.

### 6.6 PARKING BRAKE AND BRAKE LINE INSPECTION



1. Inspect the spring on the parking brake lever assembly.



2. Inspect the parking brake cable at the parking brake lever assembly on the brake caliper.



3. Inspect the brake lines and brake line connections for possible leaks or loose lines.



## 6.7 PARKING BRAKE ADJUSTMENT

### 6.7.1 PARKING BRAKE INSPECTION

1. Push the parking brake up with your hand.
2. After 2 to 4 clicks of lever travel, the vehicle should not roll while parked.
3. If the vehicle moves, adjustment is necessary.
4. Adjust the parking brake where the cable attaches to the lever assembly on the rear brake caliper.

### 6.7.2 PARKING BRAKE ADJUSTMENT

1. Place the vehicle in neutral on a flat level surface.
2. Carefully lift the rear of the vehicle off the ground and stabilize on jack stands.
3. Loosen the jam nut (A) on the rear caliper

adjustment bolt (B).

4. Tighten the adjustment bolt (B) until the rear tire will not rotate.
5. Back the adjustment bolt (B) out 1/4 turn.
6. Tighten the jam nut (A) while holding the adjustment nut (B) in place.




### 6.7.3 PARKING BRAKE REAR CALIPER REMOVAL / INSTALLATION

#### 6.7.3.1 Park Brake Caliper Disassembly / Pad Inspection

**NOTE:** Do not get oil, grease, or fluid on the park brake pads. Damage to the pads may cause the pads to function improperly.

1. Loosen the two brake caliper bolts in equal increments. Remove the bolts from the bracket and lift park brake assembly out.
2. Measure the thickness of the caliper parking brake pads. Replace pads if worn beyond the service limit.

Service Limit 0.3/64"(1 mm)



#### 6.7.3.2 Park Brake Caliper Installation

1. Install the park brake assembly into place. Tighten the two bolts in increments for proper installation.
2. Torque the two bolts to 18 ft.lbs. (24 Nm).
3. Test the park brake for proper function.

## 6.8 FRONT PAD REMOVAL / INSPECTION / INSTALLATION

**NOTE:** The brake pads should be replaced as a set.

### 6.8.1 REMOVAL

1. Elevate and support front of CUV safely.

**CAUTION:**

Use care when supporting vehicle so that it does not tip or fall. Severe injury may occur if machine tips or falls.

2. Remove the front wheel.
3. Remove the two caliper bolts and caliper from mounting bracket.
4. Push caliper piston into caliper bore slowly using a C-clamp or locking pliers with pads installed.


**NOTE:** Brake fluid will be forced through compensating port into master cylinder fluid reservoir when piston is pushed back into caliper. Remove excess fluid from reservoir as required.

5. Push mounting bracket inward and slip outer brake pad past edge. Remove inner pad.



### 6.8.2 INSPECTION

Measure the thickness of the pad friction material. Replace pads if worn beyond the service limit. Service Limit 0.3/64"(1 mm).



### 6.8.3 INSTALLATION

1. Lubricate mounting bracket pins with a light film of All Season Grease, and install rubber dust boots.
2. Compress mounting bracket and make sure dust boots are fully seated. Install pads with friction material facing each other. Be sure pads and disc are free of dirt or grease.
3. Install caliper on hub strut, and torque mounting bolts.

**Front Caliper Mounting Bolts Torque 18 ft. lbs. (25 Nm )**



4. Slowly pump the brake lever until pressure has been built up. Maintain at least 1/2 "(13 mm) of brake fluid in the reservoir to prevent air from entering the brake system.
5. Install the adjuster screw and turn clockwise until stationary pad contacts disc, then back off 1/2 turn (counter clockwise).
6. Be sure fluid level in reservoir is up to MAX line inside reservoir and install reservoir cap.

**Master Cylinder Fluid Up to MAX line inside reservoir**

7. Install wheels and torque wheel nuts.
8. It is recommended that a burnishing procedure be performed after installation of new brake pads to extend service life and reduce noise. Start machine and slowly increase speed to 30 mph. Gradually apply brakes to stop machine. Repeat procedure 10 times.

## 6.9 FRONT DISC INSPECTION / REMOVAL / REPLACEMENT

### 6.9.1 INSPECTION

1. Visually inspect the brake disc for nicks, scratches, or damage.
2. Measure the disc thickness at 8 different points around the pad contact surface using a 0-1" micrometer and a dial indicator. Replace disc if worn beyond service limit.

**Brake Disc Thickness**

**New 0.150-0.164" (3.810 - 4.166 mm)**

**Service Limit 0.140" / 3.556 mm**

**Brake Disc Thickness Variance**

**Service Limit 0.002 " (0.051 mm) difference between measurements**

3. Mount dial indicator as shown to measure disc runout on the dial indicator. Replace the disc if runout exceeds specifications.

**Brake Disc Runout**

**Service Limit 0.005" (0.127 mm)**



**6.9.2 REMOVAL/ REPLACEMENT**

1. Removal caliper and hub. Apply heat to the hub in the area of the brake disc mounting bolts to soften the bolt locking agent.
2. Remove bolts and disc.
3. Clean mating surface of disc and hub.
4. Install new disc on hub and tighten to specified.

**CAUTION:**

Always use new brake disc mounting bolts.

**Front Brake Disc Mounting Bolt**

**Torque : 18 ft. lbs. (25 Nm )**

**6.10 FRONT CALIPER REMOVAL / INSPECTION / INSTALLATION****CAUTION:**

The caliper is a non-serviceable Component; it must be replaced as an assembly.

**NOTE:** If any special service needed, contact the CUV manufacture via the agent for the parts and special instruction.

**6.10.1 REMOVAL**

1. Remove wheel, remove caliper from the strut.
2. Loosen and remove brake hose to caliper. Place a container under caliper to catch fluid draining.

**6.10.2 INSPECTION**

1. Inspect caliper body for nicks, scratches or worn. Replace caliper as an assembly if any problem exists.

**6.10.3 INSTALLATION**

1. Install caliper on hub strut, Apply Loctite™242 to screw threads and Install new bolts.

**Front Caliper Mounting Bolt Torque 18 ft. lbs. (25 Nm )**

2. Install brake hose and tighten to specified torque.

**Bolt Torque: 15 ft. lbs. (21 Nm)**

**NOTE:** If new brake pads are installed, it is recommended that a burnishing procedure be performed after installation of new brake pads to

extend service life and reduce noise. Start machine and slowly increase speed to 30 mph. Gradually apply brakes to stop machine. Repeat procedure 10 times.

## 6.11 REAR BRAKE PAD REMOVAL/INSPECTION / INSTALLATION

**NOTE:** The brake pads should be replaced as a set.

### 6.11.1 REMOVAL

1. Elevate and support rear of CUV safely.

**CAUTION:**

Use care when supporting vehicle so that it does not tip or fall. Severe injury may occur if machine tips or falls.

2. Remove the rear wheel.
3. Remove the two caliper bolts and lift caliper off of disc.

**NOTE:** When removing caliper, be careful not to damage brake line. Support caliper so as not to kink or bend brake line.

4. Push caliper piston into caliper bore slowly using a C-clamp or locking pliers with pads installed.


**NOTE:** Brake fluid will be forced through compensating port into master cylinder fluid reservoir when piston is pushed back into caliper. Remove excess fluid from reservoir as required.

5. Remove the brake pads.
6. Clean the caliper with brake cleaner or alcohol.

### 6.11.2 INSPECTION

Measure the thickness of the pad friction material. Replace pads if worn beyond the service limit.

**Service Limit 0.3/64"(1 mm)**



### 6.11.3 INSTALLATION

1. Install new pads in caliper body.
2. Install caliper and torque mounting bolts.  
**Brake Caliper Torque: 18 ft. lbs. (25 Nm )**
3. Turn adjuster screw back in finger tight using a hex wrench.
4. Slowly pump the brake lever until pressure has

been built up. Maintain at least 1/2 ".(13 mm) of brake fluid in the reservoir to prevent air from entering the brake system.

5. Install wheels, burnishing procedure should be performed.

## 6.12 REAR CALIPER REMOVAL/ INSPECTION / INSTALLATION

### CAUTION:

The caliper is a non-serviceable component; it must be replaced as an assembly.

**NOTE:** If any special service needed, contact the CUV manufacture via the agent for the parts and special instruction.

### CAUTION:

Use care when supporting vehicle so that it does not tip or fall. Severe injury may occur if machine tips or falls.

1. Safely support the rear of the machine.
2. Use a wrench to remove the brake line. Place a container to catch brake fluid draining from brake lines.
3. After the fluid has drained into the container, remove the caliper mounting bolts and remove caliper.
4. Remove brake pad as described above.
5. Inspect surface of caliper for nicks, scratches or damage and replace if necessary.
6. Install brake pads in caliper body with friction material facing each other, with the spacer between the pads. Install retaining pin through outer pad, pad spacer and inner pad.
7. Install caliper and torque mounting bolts to 18 ft.lbs. (25 Nm).
8. Install brake hose and tighten to specified torque.  
**Banjo Bolt Torque: 15 ft. lbs. (21 Nm)**
9. Bleed.
10. Field test unit for proper braking action before putting into service. Inspect for fluid leaks and firm brakes. Make sure the brake is not dragging when lever is released. If the brake drags, recheck assembly and installation.
11. Carefully lower the vehicle.

**NOTE:** If new brake pads are installed, it is



recommended that a burnishing procedure be performed after installation of new brake pads to extend service life and reduce noise.

## **6.13 REAR BRAKE DISC INSPECTION / REMOVAL / REPLACEMENT**

### **6.13.1 INSPECTION**

1. Visually inspect the brake disc for nicks, scratches, or damage.
2. Measure the disc thickness at 8 different points around the pad contact surface using a 0-1" micrometer and a dial indicator. Replace disc if worn beyond service limit.

#### **Brake Disc Thickness**

**New 0.150-0.164" (3.810 - 4.166 mm)**

**Service Limit 0.140" / 3.556 mm**

#### **Brake Disc Thickness Variance**

**Service Limit 0.002 " (0.051 mm)**

**difference between measurements**

3. Mount dial indicator as shown to measure disc runout on the dial indicator. Replace the disc if runout exceeds specifications.

#### **Brake Disc Runout**

**Service Limit 0.005" (0.127 mm)**

### **6.13.2 REMOVAL/ REPLACEMENT**

1. Removal wheel/ hub and caliper.
2. Remove bolts and disc from the flange.
3. Clean mating surface of disc and hub.
4. Install new disc on flange. Tighten to specified.

**Rear Brake Disc Mounting Bolt Torque : 18 ft. lbs.  
(25 Nm )**

#### **CAUTION:**

Always use new brake disc mounting bolts.



# CHAPTER 7 ELECTRICAL

## **7.1 PARTS INSPECTION AND SERVICE**

7.1.1 HEADLIGHT ADJUSTMENT

7.1.2 HEADLIGHT ADJUSTMENT

7.1.3 TAILLIGHT / BRAKELIGHT LAMP REPLACEMENT

## **7.2 BATTERY**

7.2.1 INSTRUCTIONS FOR SEALED TYPE DRY CHARGED STORAGE BATTERY

7.2.2 BATTERY TESTING

## **7.3 IGNITION SYSTEM**

7.3.1 IGNITION SYSTEM TROUBLE SHOOTING

7.3.2 CIRCUIT DIAGRAM

## **7.4 CHARGING SYSTEM**

7.4.1 CHARGING SYSTEM CIRCUIT DIAGRAM

7.4.2 CHARGING SYSTEM

## **7.5 ELECTRICS STARTING SYSTEM**

7.5.1 DIAGRAM

7.5.2 TROUBLE SHOOTING

## **7.6 LIGHTING SYSTEM**

7.6.1 DIAGRAM

7.6.2 FOR EUROPE MODEL

7.6.3 TROUBLE SHOOTING

7.6.4 LIGHT SYSTEM CHECK

## **7.7 REVERSE LIMIT SYSTEM**

## **7.8 GEAR POSITION INDICATOR SWITCH TEST**

## **7.9 SPEEDOMETER SYSTEM**

7.9.1 OPERATION OF SPEED SENSOR

7.9.2 LCD Meter

## **7.10 MAIN SWITCH**

## **7.11 FUEL GAUGE/ FUEL LEVEL SENSOR**

## **7.12 WIRING DIAGRAM**

## 7.1 PARTS INSPECTION AND SERVICE

### 7.1.1 HEADLIGHT ADJUSTMENT

1. Use bulb 12V 35W/35W.
2. Remove the black sheath, turning the socket counterclockwise and take it out. Turning the bulb counterclockwise and Remove it from the socket.
3. Change the bulb.



### 7.1.2 HEADLIGHT ADJUSTMENT


1. The headlight beam can be adjusted vertically.
2. Place the vehicle on a level surface with the headlight approximately 33 in(10m) from a wall.
3. Measure the distance from the floor to the center of the headlight and make a mark on the wall at the same height.
4. Start the engine and turn the headlight switch to high beam.
5. Observe headlight aim. The most intense part of the headlight beam should be aimed 86mm to129mm below the mark placed on the wall in step 2.



**NOTE:** Riding weight must be included on the seat.

6. Loosen but not remove pivot bolt/ screw and adjust beam to desired position.
7. Tighten nut and bolt / screw.

To turn the two adjusting screws backward is to lower the beam. To turn the two adjusting screws forward is to heighten the beam.



### 7.1.3 TAILLIGHT / BRAKELIGHT LAMP REPLACEMENT

1. From the rear of the taillight remove two screws holding lens cover in place and remove lens cover.
2. Remove lamp and replace it with recommended lamp.
3. Reinstall the lens cover removed in step 1.
4. Test the taillight / brake light.



## 7.2 BATTERY

Battery electrolyte is poisonous. It contains sulfuric acid. Serious burns can result from contact with skin, eyes or clothing Antidote:

**External:** Flush with water.

**Internal:** Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call physician immediately.

**Eyes:** Flush with water for 15 minutes and get prompt medical attention.

Batteries produce explosive gases. Keep sparks, flame, cigarettes, etc. away. Ventilate when charging or using in an enclosed space. Always shield eyes when working near batteries.

### KEER OUT OF REACH OF CHILDREN

**WARNING:** The gases given off by a battery are explosive. Any spark or open flame near a battery can cause an explosion which will spray battery acid on anyone close to it. If battery acid gets on anyone, wash the affected area with large quantities of cool water and seek immediate medical attention.

#### 7.2.1 INSTRUCTIONS FOR SEALED TYPEDRY CHARGED STORAGE BATTERY

This battery is dry and charged, which means that it starts operating when being filled with the electrolyte and sealed with the sealing plugs.

To fill the electrolyte proceed as follows:

- (1) Place the battery on a level place, and tear down the sealed tape on even place.
- (2) Softly inlay the filling funnel on the ports the storage battery.
- (3) Take out the electrolyte container. Put it down straightly. Then pour through the funnel to the ports.

**CAUTION:** Unless the electrolyte container is pushed in straightly, the battery may fall down, from which spillages may cause loss of eyesight and/or burns.

- (4) Be sure that bubbles are generating in all 6 cells of the electrolyte container and the level of electrolyte should be down.

**CAUTION:** If there is any cell which does not produce bubbles, tap it softly with finger and filling will start.

Removing the electrolyte container from the battery is not necessary.

#### 7.2.2 BATTERY TESTING

Whenever a service complaint is related to either the starting or charging systems, the battery should be checked first.

Following are three tests which can easily be made on a battery to determine its condition:

OCV Test, Specific Gravity Test and Load Test.

**MF (Maintenance Free) battery does not require the Specific Gravity Test and Refill Open Circuit Voltage Test**

Battery voltage should be checked with a digital multimeter. Readings of 12.6 or less require further battery testing and charging.

**NOTE:** Lead acid batteries should be kept at or near a full digital multimeter.

### Load test

**CAUTION:** Remove spark plug high tension leads and connect securely to engine ground before proceeding.

**NOTE:** This test can only be performed on machines with electric starters. This test cannot be performed with an engine or starting system that is not working properly.

A battery may indicate a full charge condition in the OCV test and the specific gravity test, but still may not have the storage capacity necessary to properly function in the electrical system. For this reason, a battery capacity or load test should be conducted whenever poor battery performance is encountered. To perform this test, hook a multimeter to the battery in the same manner as was done in the OCV test. The reading should be 12.6 volts or greater. Engage the electric starter and view the registered battery voltage while cranking the engine. Continue the test for 15 seconds. During this cranking period, the observed voltage should not drop below 9.5 volts. If the beginning voltage is 12.6 or higher and the cranking voltage drops below 9.5 volts during the test, replace the battery.


## 7.3 IGNITION SYSTEM

### 7.3.1 IGNITION SYSTEM TROUBLE SHOOTING

#### No Spark, Weak or Intermittent Spark

- Spark plug gap incorrect
- Fouled spark plug
- Faulty spark plug cap or poor connection to high tension lead
- Related wiring loose, disconnected, shorted, or corroded
- Emergency switch faulty
- Terminal board or connections wet, corroded
- Poor ignition coil ground (e.g. coil mount loose or corroded)
- Faulty stator (measure resistance of all ignition related windings)
- Incorrect wiring (inspect color coding in connectors etc.)
- Faulty ignition coil winding (measure resistance of primary and secondary)
- Worn magneto (RH) end crankshaft bearings
- Sheared flywheel key
- Flywheel loose or damaged
- Trigger coil air gap too wide (where applicable) should be 0.030-0 .050" (0.75-1.25 mm)
- Excessive crankshaft run out on magneto (RH) end should not exceed 0.005"(0.13mm)
- Faulty ECU module
- Faulty Electric relay

7.3.2 CIRCUIT DIAGRAM




**IF THE IGNITION SYSTEM FAILS TO OPERATE**

**Procedure**


Check:

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Fuse (Main)</li> <li>2. Battery</li> <li>3. Spark plug</li> <li>4. Ignition spark gap</li> <li>5. Spark plug cap resistance</li> </ol> | <ol style="list-style-type: none"> <li>6. Ignition coil</li> <li>7. Main switch</li> <li>8. Emergency stop switch</li> <li>9. Wiring connection (entire ignition system)</li> </ol> |
|--|---|


**1. Fuse (Main)**




**2. Battery**




### 3. Spark plug



Spark plug gap: 0.6~0.7mm




### 4. Ignition spark gap






Minimum spark gap: 6mm (0.24 in).

### 5. Spark plug cap resistance



**NOTE:**

- When removing the spark plug cap, do not pull the spark plug cap from high tension cord.
- Remove →Turning counterclockwise.
- Connect →Turning clockwise.
- Check the high tension cord when connecting the spark plug cap.
- When connecting the spark plug cap, cut the high tension cord about 5mm.




**Tester (+) lead  
Spark plug side ①  
Tester (-) lead  
High tension cord side ②**




Spark plug cap resistance: 5KΩ (20 °C).

### 6. Ignition coil resistance




- **Primary coil resistance:  $0.28\Omega \pm 10\%$  (20 °C).**




**Tester (+) lead  
Light Green Terminal  
Tester (-) lead Black  
Terminal**

- Secondary coil resistance:  $2.8K\Omega \pm 10\%$  (20°C)




Tester (+) lead  
 Spark plug lead  
 Tester (—) lead  
 Light Green Terminal


**7. Main switch**



**8. Emergency switch**




### 9. Wiring connection



## 7.4 CHARGING SYSTEM

### 7.4.1 CHARGING SYSTEM CIRCUIT DIAGRAM




### CURRENT DRAW - KEY OFF

**CAUTION:** Do not connect or disconnect the battery cable or ammeter with the engine running. Damage will occur to light bulbs.

Connect an ammeter in series with the negative battery cable. Check for current draw with the key off, if the draw is excessive, loads should be disconnected from the system one by one until the draw is eliminated. Check component wiring as well as the component for partial shorts to ground to eliminate the draw.

<b>Current draw key off:</b>
<b>Maximum of 0.01DCA(10mA)</b>




### 7.4.2 CHARGING SYSTEM


#### Check procedure

1. Fuse (Main)
2. Battery charging
3. Charging voltage
4. Stator coil resistance
5. Wiring system (entire system)


1. Fuse



2. Battery




3. Charging voltage




NOTE: Use a fully charged battery.

4. Starter coil resistance




## 5. Wiring connection



7.5 ELECTRICS STARTING SYSTEM

7.5.1 DIAGRAM




7.5.2 TROUBLE SHOOTING

IF THE STARTER MOTOR FAILS TO OPERATE


Check procedure

- |                  |   |
|------------------|---|
| 1. Fuse (Main)   | 5. Main switch                                |
| 2. Battery       | 6. Engine stop switch                         |
| 3. Starter motor | 7. Front/rear brake switch                    |
| 4. Starter relay | 8. Starter switch                             |
|                  | 9. Wiring connection (entire starting system) |


1. Fuse (Main)




2. Battery



3. Starter motor




4. Starter relay




**WARNING:**

A wire used as a jumper lead must have the equivalent capacity as that of the battery lead or more, otherwise it may burn.




This check is likely to produce sparks, so be sure that no flammable gas or fluid is in the vicinity.


**5. Main switch**




**6. Emergency stop switch**




**7. Front/rear brake switch**



8. Starter switch




9. Wiring connection



7.6 LIGHTING SYSTEM

7.6.1 DIAGRAM




7.6.2 TROUBLESHOOTING


Check procedure

1. Fuse (Main)
2. Battery
3. Main switch
4. Lights switch
5. Distance light switch
6. Wiring connection (entire lighting system)


1. Fuse (Main)




2. Battery




3. Main switch




4. Lights switch



5. Distance light switch




6. Wiring connection (entire lighting system)




7.6.3 LIGHT SYSTEM CHECK

7.6.3.1 If the headlight and the high beam indicator light fail to come on

1. Bulb and bulb socket




2. Voltage




7.6.3.2 The taillight fails to come on


1. Bulb and bulb socket



2. Voltage



7.7 REVERSE LIMIT SYSTEM




Speed is controlled by the ECU factory Settings In the 15 km/h, which can be reset in accordance with the user's practice.

**NOTE:**  
This limit can be released by the override switch.




7.8 GEAR POSITION INDICATOR SWITCH TEST  
7.8.1 Switch table



	E	A	B	C	D	
High Range	●	●				
Low Range	●		●			
Neutral	○			○		
Reverse	○				○	

<p><b>1.Low range</b> The LCD screen show “L” below the middle position.</p>	
<p><b>2.High range</b> The LCD screen show “H” below the middle position.</p>	
<p><b>3.Neutral</b> The LCD screen show “N” below the middle position. Neutral light is lit.</p>	
<p><b>4.Reverse</b> The LCD screen show “R” below the middle position.</p>	

7.8.2 Switch schematic



7.9 SPEEDMETER SYSTEM

7.9.1 OPERATION OF SPPEED SENSOR

7.9.1.1 Speed Sensor is on the rear axle

Operation Instructions of Electric Dial Meter and Speed Sensor/ Operation Instructions of LCD Meter and Speed Sensor

A. Hall Sensor is a new type sensor used to measure speed, angle, revolution and length, etc by means of voltage pulse signals converted from sensing gear ratio of black metal gear or gear rack.

B. Main Technical Parameter for sensor:


Item	Code	Vol value	Unit
Operating voltage	Vcc	5-20	V
Operating current	Icc	≤15	mA
Low voltage output	Vol	≤ 0.4	V
Hight voltage output	Voh	≥ (Vcc-1)	V
Operating distance	D	1mm ≤ D ≤ 2.5mm	mm

C. The following is the graphic illustration for sensor installation, Wire 1 (red) is positive and wire 2 (black) negative, Wire 3 (yellow) works as the one to output signals.


**Note:** Always screw in the sensor by hand when installation or adjustment.

1. Align one tooth of the splines to the centre of the hole of the sensor by turning the rear axle.
2. Screw the sensor in (CW) by hand slightly until resistance is felt.
3. Turn the sensor CCW by 1 to 2 turn(s).
4. Tighten the jam nut.

7.9.1.2 Operation Instructions of the Meter assembly




7.9.2 LCD METER



- |                              |   |
|------------------------------|---|
| 1. Left turn signal lamp     | 10. Oil position show                               |
| 2. High beam indicator light | 11. Engine rpm meter                                |
| 3. Safe belt indicator       | 12. Reverse indicator light                         |
| 4. LCD show                  | 13. Electric fuel injection failure alarm indicator |
| 5. Km/h/ mile/h selector     | 14. Lamp switch indicator                           |
| 6. Fuction button            | 15. Water temperature alarm indicator               |
| 7. The odometer              | 16. Oil level alarm light                           |
| 8. Trip/ Total selector      | 17. Parking light                                   |
| 9. Battery alarm indicator   |   |

7.10 MAIN SWITCH AND HANDLE SWITCH

	R	R/B	G	R/Y
OFF				
ON	○—○			
START	○—○		○—○	




DJ70413-6. 3-11



## 7.11 FUEL GAUGE/ FUEL LEVEL SENSOR

### 7.11.1 Removal

- Turn the ignition switch to “OFF” .
- Remove two connecting pipe of oil pump.
- Remove the terminal of oil pump.
- Remove the oil pump cover.
- Retain plate and fuel level sensor from the fuel tank.




### 7.11.2 Installation

- Install rubber oil seal to the oil pump.
- Install oil pump to the fuel tank, location to align.
- Install the oil pump cover.
- Install two connecting pipe of oil pump.
- Install the terminal of oil pump.



### 7.11.3 Fuel Gauge / Fuel level Sensor Inspection


- Move the float to the bottom (RESERVE) position, turn the ignition switch to “ON” and check the fuel gauge.



- When shows that there are only two segments, segments should blink.
- With the fuel level sensor float at the top (FULL) position, turn the main switch to "ON" and check the fuel gauge. All segments up to segment "F" should come on.
- If all of the six segments blink, check the wiring connection of fuel level system. Refer to "Circuit of the fuel level"
- If the fuel gauge does not function properly, check the fuel level sensor. If the fuel level sensor is OK, replace the LCD Meter.

**7.11.4 Fuel level Sensor Inspection**


- Disconnect the fuel level sensor 2p Green connector and connect the ohmmeter to the sensor side connector terminals.
- Measure the fuel level sensor resistance with the float at the top (FULL) and bottom (RESERVE) positions.



FLOAT POSITION	RESISTANCE(20°C/ 68° F)
TOP(FULL)	0-12 Ω (±2 Ω)
BOTTOM(RESERVE)	94-110 Ω (±2 Ω)

7.12 WIRING DIAGR

Note	Colour
R	Red
Y	Yellow
Br	Brown
L G	Light Green
G/R	Green/Red
W/R	White/Red
P	Pink
G	Green
G/B	Green/Black
G/Y	Green/Yellow
Y/W	Yellow/White
Or	Orange
B/W	Blue/White
R/B	Red/Blue
B/Y	Black/Yellow
L B	Light Blue
D G	Dark Green
Br/R	Brown/Red
B/Y	Blue/Yellow
B/B	Blue/Black
Pu/W	Purple/White
Y/R	Yellow/Red
R/W	Red/White
Gr/R	Gray/Red
Br/G	Brown/Green
G/W	Green/White
B/G	Black/Green
B/W	Black/White
Gr	Gray
Gr/W	Gray/White
Br/R	Brown/Red







**MASSIMO**

[www.massimomotor.com](http://www.massimomotor.com)

